List of M20d DSP Presets available in firmware version 1.20

GENERAL: **DRUMS:** Hi hat 2 Aux in (stereo) **Bongos** Ride CD Player (stereo) Cajon Combi 1/4" Clave Tuned percussion: Combi XLR Congas Glockenspiel DJ Mixer Cowbell Marimba DJ Mixer (stereo) Vibraphone Djembe DVD Player (stereo) Doumbek **Xylophone** Laptop (stereo) Large drum Line More cowbell Toms: Line (stereo) Percussion Floor tom MP3 Player Shaker Floor tom 2 MP3 Player (stereo) Small drum Floor tom 3 **Tambourine** Mic Rack tom Mic (1/4") Rack tom 2 Mic (stereo) Electronics: (still under Rack tom 3 Mic 1/4" (stereo) drums) Click **BASS:** Sub mixer Sub mixer (stereo) Drum machine Bass cab Drum pad (stereo) Bass cab 2 Vocal: Drum pads Bass cab 3 Female: Bass direct Female back Snare: Bass direct 2 Female delay Country snare Bass modeler Female doubled Country snare 2 Bass modeler (stereo) Fat snare Female lead Bass synth Piccolo snare Female w/ reverb Sub Female megaphone Snare Snare bottom Acoustic: Speech: Acoustic bass guitar Headset Kick: Upright bass Lavalier Big kick Upright bass 2 Mic Country kick Upright bass 3 Mic (stereo) Hip hop kick Upright bass DI Podium Jazz kick Kick **GUITAR:** Male: Kick 2 Elec amp direct Male back Kick pzm Elec pod direct Male delayed Metal kick Guitar combo

Male doubledMetal kick pzmGuitar combos (stereo)Male leadSubsonicGuitar modelerMale w/ reverbCymbals:Guitar stackMale MegaphoneCrashLap steelHi hatPOD direct

List of M20d DSP Presets available in firmware version 1.20

POD HD 500 (stereo) Other:

Pedal steel Accordion Strings:
Accordion 2 Cello

Fretted instruments:Accordion 3Contra bassBanjoCelesteElect violin 1Banjo mic'dElec accordionElec violin 2

Banjo mic'd Elec accordion Elec violin 2
Banjo mic'd 2 Melodica Elec violin 3

Mandolin direct Elec violin 3 (stereo)

Mandolin mic'd Acoustic piano: Fiddle

Sitar Grand piano Strings
Ukulele direct Grand piano (stereo) Viola
Ukulele mic'd Grand piano 2 Violin

Ukulele mic'd Grand piano 2 Vi

Ukulele mic'd 2 Grand piano 2 (stereo)
Grand piano 3

Acoustic:Grand piano 3 (stereo)Drum fill12 string DIRock piano (stereo)Front fill

Acoustic chorus Upright Headphones (stereo)
Acoustic direct Upright 2 In ear

OUTPUT:

Acoustic mic'd Upright piano (stereo) In ears (stereo)
Acoustic mic'd 2 Upright piano 2 (stereo) Line out

Acoustic finger pick Upright piano 3 (stereo) Mix out (stereo) Flamenco guitar Monitor

Nylon direct WINDS AND STRINGS: Monitor (stereo)
Nylon direct 2 Bagpipes Monitor wedge
Nylon mic'd Harmonia Record out

Nylon mic'd 2

Resonator DI

Brass:

Side fill

Side fills (stereo)

Small wedge

Resonator mic'd Brass Small wedge Brass 2 Vocal KEYS:

B3 Trombone ARTIST PRESETS:
Basic keys Trumpet Brad Madix
Basic keys (stereo) Tuba Bright vocal

Clavinet Drum bus crush (stereo)

KeysWoodwinds:Rock bassKeys (stereo)Alto saxRock guitarRhodesBaritone saxRock kickSynth bassClarinetRock snare

Synth bass (stereo) Flute
Synth chords Flute 2 **D. DiGiovanni**Synth chords (stereo) Sax Piano mic high

Synth lead Sax section Piano mic low Synth lead (stereo) Soprano sax

Tenor sax

Wurli